



## Lochinvar Boilers

- Hot Surface Igniter
- Pilot Assembly
- Pressure Switches
- Ignition Module
- Heat Exchanger (Continuous Duty Applications)



To order these or other parts contact the Ryan Company  
(952) 915-6475 PH • (952) 915-6480 FX • [www.ryancompanyinc.com](http://www.ryancompanyinc.com)

Consult your owners manual for actual part numbers and installation procedures. If you do not have an owners manual please provide the model number and serial number.